AMERICAN EAGLE®
FOOD MACHINERY, INC.

AE-G12N Meat Grinder

PARTS LIST & ASSEMBLY DIAGRAM

AE-G12/01	Comple Motor	AE-G12/30	Spring Cylinder Pin ϕ 8 × 30
AE-G12/02	Nut	AE-G12/31	Ball Bearing(6205)
AE-G12/03	Worm	AE-G12/32	Shaft Worm
AE-G12/04	Oil seal	AE-G12/33	Key 6 × 5 × 14
AE-G12/05	Screw(3pcs) M8 × 25	AE-G12/34	Worm Gear
AE-G12/06	Key 3 × 3 × 28	AE-G12/35	Spacer
AE-G12/07	Coupling Cover Nut	AE-G12/36	Ball Bearing(6203)
AE-G12/08	Presscere Plate(6mm/8mm)	AE-G12/37	C-Type Snap Ring
AE-G12/09	Reamer(1pc)	AE-G12/38	Gear Box
AE-G12/10	Holder	AE-G12/39	Cover
AE-G12/11	Spiral Propeller	AE-G12/40	Bottom Plate
AE-G12/12	Plunger	AE-G12/41	Rubber legs
AE-G12/13	Teferlon Washer	AE-G12/42	Cap Screws(4pcs) M6 × 15
AE-G12/14	Key ϕ 3.50	AE-G12/43	Meat Funnel
AE-G12/15	T-type Chamber	AE-G12/44	Meat Pusher
AE-G12/16	Key ϕ 8SS	AE-G12/45	Circuit Breaker
AE-G12/17	Oil Bearing	AE-G12/46	REV/FOR Switch
AE-G12/18	Screws (3pcs) M8 × 25	AE-G12/47	Cap screws(4pcs) M3 × 12
AE-G12/19	Housing	AE-G12/48	Capacitor
AE-G12/20	Feeder Pan	AE-G12/49	Cap Screws
AE-G12/21	Screw Driver 8mm	AE-G12/50	Turning Handle
AE-G12/22	Screw (2pcs) M8 × 30	AE-G12/51	Specification Plate
AE-G12/23	Handle	AE-G12/52	Cap Screw
AE-G12/24	Oil Taper M12 × 14	AE-G12/53	Cable Tie
AE-G12/25	Thumb Screw	AE-G12/54	Power Cord Set & Plug
AE-G12/26	Screws(3pcs) M8 × 35	AE-G12/55	Centrifugal Govemor Plate
AE-G12/27	Attachment Hub	AE-G12/56	Cap Screws
AE-G12/28	Oil Seal 45 × 30 × 8	AE-G12/57	Cap Screws
AE-G12/29	Shaft-Hub	AE-G12/58	Centrifugal Govemor



AE-G12N Meat Grinder
ELECTRICAL DIAGRAM

CB: Starting Capacitor
CA: Operating Capacitor

PARTS LIST



ASSEMBLY DIAGRAM

AMERICAN EAGLE FOOD MACHINERY, INC.
3557 South Halsted Street, Chicago, Illinois 60609-1606
Tel:(773)376-0800, Fax(773)376-2010, Customer Service (888)390-0800, Expediout Service: (800)836-5756